



HSM Wire International, Inc

Ph: 330-244-8501 Fax: 330-244-8561

www.hsmwire.com

Formulas

To be used as a guideline only.

Calculation of the Nominal Overall Diameter

$$D = p \times \sqrt{n} \times d$$

Where:

D	Nominal bunched wire Diameter
p	Nominal bare Diameter of conductor
n	Number of Single Wires
d	Nominal overall diameter of the single wire

Calculation of the Cross Section of Conductor

$$q = \frac{\pi}{4} \times d^{2nom.} \times n$$

Where:

q	Nominal cross-section (conductive material)
d nom.	Nominal bare diameter of conductor
n	Number of Single Wires
d	Nominal outer diameter of a single wire

Calculation of the Litz Resistance

$$\text{Nominal Resistance} = \frac{\text{Nominal resistance of single wire} \times k_1}{\text{Number of single wires}}$$

$$\text{Minimum Resistance} = \frac{\text{Minimum resistance of single wire} \times k_1}{\text{Number of wires}}$$

Maximum Resistance

a) Number of wires up to and including 25

$$\text{Maximum Resistance} = \frac{\text{Maximum resistance of single wire} \times k_1}{\text{Number of single wires}}$$

b) Number of wires over 25

$$\text{Maximum Resistance} = \frac{\text{Maximum resistance of single wire} \times k_1 \times k_2}{\text{Number of single wires}}$$

The factor k_1 is 1.02 and is taken because of the decrease in length due to bunching k_1 for

- 1 x bunched = 1.02
- 2 x bunched = 1.04
- 3 x bunched = 1.06

The factor k_2 is 1.03 and is taken because of the broken ends which may occur.